

ADJ VINTAGE BAR - DMX TRAITS

MODE / CHANNEL									VALUES	FUNCTION
5CH	7CH	11CH	17CH	21CH	84CH	91CH	93CH	100CH		
1	1	1	1	1					0-255	All Amber, 0~100%
					1	1	1	1	0-255	Amber 1, 0~100%
					2	2	2	2	0-255	Amber 2, 0~100%
					3	3	3	3	0-255	Amber 3, 0~100%
					4	4	4	4	0-255	Amber 4, 0~100%
										Amber Shutter, Strobe
									0-31	LEDs Off
									32-63	LEDs On
									64-95	Strobe effect slow to fast
		2	2	2		5	5	5	96-127	LEDs On
									128-159	Pulse-effect in sequences
									160-191	LEDs On
									192-223	Random strobe effect slow to fast
									224-255	LEDs On
	2	3	3	3		6	6	6	0-255	Amber Dimmer (Intensity), 0~100%
		4	4	4		7	7	7	0-255	Amber Dimmer Fine (Intensity)
2	3	5	5	5					0-255	All Red, 0~100%
3	4	6	6	6					0-255	All Green, 0~100%
4	5	7	7	7					0-255	All Blue, 0~100%
5	6	8	8	8					0-255	All Lime, 0~100%
					5	8	8	8	0-255	Red 1, 0~100%
					6	9	9	9	0-255	Green 1, 0~100%
					7	10	10	10	0-255	Blue 1, 0~100%
					8	11	11	11	0-255	Lime 1, 0~100%
...
					81	84	84	84	0-255	Red 20, 0~100%
					82	85	85	85	0-255	Green 20, 0~100%
					83	86	86	86	0-255	Blue 20, 0~100%
					84	87	87	87	0-255	Lime 20, 0~100%
				9				88	0-255	RGBL Color Macros
										RGBL Shutter, Strobe
									0-31	LEDs Off
									32-63	LEDs On
									64-95	Strobe effect slow to fast
		9	9	10		88	88	89	96-127	LEDs On
									128-159	Pulse-effect in sequences
									160-191	LEDs On
									192-223	Random strobe effect slow to fast
									224-255	LEDs On
	7	10	10	11		89	89	90	0-255	RGBL Dimmer (Intensity), 0~100%
		11	11	12		90	90	91	0-255	RGBL Dimmer Fine (Intensity)
										Amber Internal Programs:
									0-19	Off
									20-50	Program 1
									51-80	Program 2
			12	13				92	81-110	Program 3
									111-140	Program 4
									141-170	Program 5
									171-200	Program 6
									201-230	Program 0
									231-255	No Function
			13	14				93	0-255	Amber Internal Programs Speed, Slow → Fast
			14	15				94	0-255	Amber Internal Programs Fade, Least to Most

DMX TRAITS

MODE / CHANNEL									VALUES	FUNCTION
5CH	7CH	11CH	17CH	21CH	84CH	91CH	93CH	100CH		
			15	16				95		RGBL Background Programs:
									0-19	Off
									20-50	Program 1
									51-80	Program 2
									81-110	Program 3
									111-140	Program 4
									141-170	Program 5
									171-200	Program 6
									201-230	Program 0
									231-255	No Function
			16	17				96	0-255	RGBL Background Programs Speed, Slow →Fast
			17	18				97	0-255	RGBL Background Programs Fade: Least to Most
										Dim Mode
									000-020	Default to Unit Setting
									021-040	Standard
									041-060	Stage
									061-080	TV
									081-100	Architectural
									101-120	Theatre
									121-140	Stage 2
										Dim Speed
									141	0.1 s
									142	0.2 s
									143	0.3 s
									144	0.4 s
									145	0.5 s
				19			91	98	146	0.6 s
									147	0.7 s
									148	0.8 s
									149	0.9 s
									150	1 s
									151	1.5 s
									152	2 s
									153	3 s
									154	4 s
									155	5 s
									156	6 s
									157	7 s
									158	8 s
									159	9 s
									160	10 s
									161-255	Default to Unit Setting
										Dim Curves
									0-20	Square
				20			92	99	21-40	Linear
									41-60	Inv. Squa
									61-80	S. Curve
									81-255	No Function

DMX TRAITS

MODE / CHANNEL									VALUES	FUNCTION
5CH	7CH	11CH	17CH	21CH	84CH	91CH	93CH	100CH		
				21		91	93	100		Special Functions
									0-15	Default to Unit Setting
									16-30	900HZ
									31-45	1000HZ
									46-60	1100HZ
									61-75	1200HZ
									76-90	1300HZ
									91-105	1400HZ
									106-120	1500HZ
									121-135	2500HZ
									136-150	4000HZ
									151-165	5000HZ
									166-180	6000HZ
									181-195	10000KHZ
									196-210	15000KHZ
									211-225	20000KHZ
									226-229	25000KHZ
									230-233	Enable Bluetooth (Hold 3s)
									234-238	Disable Bluetooth (Hold 3s)
									239-243	Enable Pixel Flip (Hold 3s)
									244-248	Disable Pixel Flip (Hold 3s)
									249-255	No Function