

CSS8018

Commercial Series Ceiling Speaker

INSTALLATION INSTRUCTIONS

- 1. Install according to diagram.
- 2. Connect leads according to Tap Wiring chart.
- 3. Cut off bare portion of unused leads and terminate with wire nuts.

Note: Always install in accordance with applicable electrical and building codes.

Tap Wiring:


| | Orange | Green | Gray | Yellow | Black |
|------|--------|-------|-------|--------|-------|
| 25V | 1.3W | 2.5W | 5W | 10W | СОМ |
| | White | Blue | Brown | Orange | Black |
| 70V | 1.3W | 2.5W | 5W | 10W | СОМ |
| 100V | 2.5W | 5W | 10W | N/C | СОМ |



JBL Professional 8500 Balboa Boulevard, P.O. Box 2200 Northridge, California 91329 U.S.A.

Tile Rails CSS-TR4/8 (x2)

Secure to ceiling/grids in manner required by local building code.



Back Can CSS-BB8

Back Can / Tile Rail screws (machine screws) M4 x 8 mm (4 places, packaged with back can)

Install screw through thru-hole in back can, and screw into tile rail.

Ceiling Material

CSS8018 Speaker

Speaker screws (sheet metal screws) M4 x 40 mm (4 places, packaged with speaker)

Install screw through thru-hole in speaker, screw into clip nut in back can.

CSS8018 Instr 06/10